Cruze Sunroof

Quick reference guide

⚠Warning

Always observe the following precautions:

Do not place fingers or objects near the sunroof when operating.

Do not place heavy objects on or around the sunroof.

Remove debris from the outside of the sunroof.

When leaving the vehicle unattended, close the sunroof fully.

As at all other times, all occupants must wear their safety belts whether the sunroof is open or closed.

Failure to observe these precautions may result in personal injury or damage to your vehicle.

Fitting an aftermarket sunroof may void the warranty on your vehicle and could result in injury to the vehicle occupants in the event of an accident.

The sunroof:

- Will operate with the ignition in the on position.
- Will operate for 10 minutes after switching the ignition off or until a front door is opened.

Open or close

Press or gently to first detent: sunroof is opened or closed as long as the switch is operated.

Press or firmly to the second detent and then release: the sunroof is opened or closed automatically with enabled safety function. To stop the movement, operate the switch once more.

Raise or close

Press or : sunroof is raised or closed automatically.

Safety function

If the sunroof encounters resistance during automatic closing, it is immediately stopped and opened again.

Override safety function

In the event of closing difficulties due to frost or the like, hold the switch pressed until the sunroof is closed.

Sunblind

The sunblind is operated manually. Close or open the sunblind by sliding. When the sunroof is open, the sunblind is always open.

Cleaning and maintenance

Regularly clean the glass, seals and roof flanges with a moist, soft cloth.

Printed in Australia
Part no. 92256575
December 2010
(MY10 JG Cruze sunroof operation. Print 2)
© 2010 GM Holden Ltd
Reproduction in whole or part is prohibited
without written approval from GM Holden Ltd,
ABN 84 006 893 232

HOLDEN

This supplement should be kept together with the owner's handbook in the glovebox of your vehicle.